

# Motor Mount Conversion Chrysler 3.3L

# ENGINEQUEST®

(800) 426-8771

## Converts Transverse Drives (block casting # 4556430, 4621944 & 4621763) to Longitudinal Drive



without boss



MMA202



with boss

- #1 Use a 21/64" drill bit for locating center of original motor mount boss hole.
- #2 Using a 17/32" drill bit, bore completely thru block in both front and rear motor mount boss.
- #3 With a 5/8"-11 Starting Tap, completely thread both holes.  
(pay attention as not to make hole at an angle)
- #4 With a 3/4" Chamfering Bit, chamfer both holes .100" deep.
- #5 Use a High Strength Lock-Tight (or equivalent) on external threads of adaptor.
- #6 Install .815" adaptor in rear mount by using a 10x1.5mm bolt with washer.
- #7 Install .430" adaptor in front mount by using a 10x1.5mm bolt with washer.

Drill



Tap



Chamfer



Install



**Must use  
block casting  
numbers  
4556430,  
4621944,  
4621763**



**Enginequest, Inc.**

2580 N. Commerce Street

N. Las Vegas, NV. 89030

(800) 426-8771

(702) 649-6777 fax

web site

[www.enginequest.com](http://www.enginequest.com)

e-mail

[sales@enginequest.com](mailto:sales@enginequest.com)